



Arctic Cat M8000 Mountain Cat Alpha one 2019

FLS-98022

Written By: Nicolas



Step 1 — Arctic Cat M8000 Mountain Cat Alpha one 2019



- Lift the front of the snowmobile in such a way that the skis are off the ground.
- Remove the stock shocks according to the procedures recommended by the manufacturer.
- Install the Elka front shocks with the piggyback reservoir at the top and pointing forwards of the snowmobile as shown

Step 2



- Remove the limiter strap.
- Lift the rear of the snowmobile in such a way that the track is not touching the ground.
- Remove the stock suspension.
- Install the stock bushing with both spacer mount on each side of the bottom eyelet.
- Install the Elka center shock with piggyback reservoir at the top and pointing towards the right side of the snowmobile as show on the photo.

Step 3



- Install the Elka rear shock with the piggyback reservoir install on the right side with the rebound facing upwards as shown on the photo.
- Lower the snowmobile completely and re-install the limiter strap.