



# Polaris RZR 900 TRAIL (2015-up)

FLS-30398

Written By: Steve Boulay





## Step 1 — REMOVE THE STOCK SHOCKS



- **FRONT SHOCKS:** Remove the stock shocks. Refer to the vehicle's owner manual if needed.

## Step 2 — FRONT SHOCKS INTALLATION



- **FOR STAGE 1 & STAGE 2 MODELS:** Install the Elka shocks with the Shraeder nitrogen valve towards the outside of the vehicle.
- **FOR STAGE 3/4/5 & LEGACY SERIES MODELS :** Install the Elka shocks with the piggyback reservoirs pointing towards the rear and outside of the vehicle.



### Step 3 — REMOVE THE STOCK SHOCKS



- **Rear shocks:** Remove the stock shocks. Refer to the vehicle's owner manual if needed.

### Step 4 — REAR SHOCKS INTALLATION



- **FOR STAGE 1 & STAGE 2 MODELS:** Install the Elka shocks with the Shraeder nitrogen valve towards the outside of the vehicle.
- **FOR STAGE 3/4/5 & LEGACY SERIES MODELS:** Install the Elka shocks with the piggyback reservoirs pointing towards the rear and outside of the vehicle as shown on photo A (left side shown).