



# CAN-AM DEFENDER HD7/HD9/HD10 XT/XTP/DPS

FLS-213005

Written By: Jean-Philippe Dextraze



## Step 1 — Removing Stock Shocks



- Lift the vehicle using a jack or stand so that the wheels are off the ground. Refer to your vehicle's owner manual for specific instructions on how to remove the stock shocks. Keep your original bolts to re-use when installing your new Elka shocks..



## Step 2 — Install Right Front Shock



- Install the front new Elka shocks with the reservoir ( on Stage 3-4-5 ) or Schraeder nitrogen valve ( on Stage 1-2 ) at the top of vehicle. ( Right side shown ). The reservoir must be orientated outwards

## Step 3 — Install Right Front Shock (continued)



- On Stage 2, Stage 4 and Stage 5 models, the lower shock eyelets should be installed with the rebound adjuster (red square) oriented towards the back of the vehicle as shown by the Red square on the photo ( Right side shown ). If needed, you can turn the lower eyelet to orient properly.

## Step 4 — Install Left Front Shock



- Install the front new Elka shocks with the reservoir ( on Stage 3-4-5 ) or Schraeder nitrogen valve ( on Stage 1-2 ) at the top of vehicle. ( left side shown ). The reservoir must be orientated outwards.

## Step 5 — Install Left Front Shock (continued)



- On Stage 2, Stage 4 and Stage 5 models, the lower shock eyelets should be installed with the rebound adjuster (red square) oriented towards the back of the vehicle as shown by the Red square on the photo ( left side shown ). If needed, you can turn the lower eyelet to orient properly.

## Step 6 — Installing Right & Left Rear Shock



- Install the left and right new Elka rear shock with the piggyback reservoir at the top and oriented towards the front of the vehicle as indicated by the red Arrow on the photo.
- On Stage 1 and Stage 2, the left and the right shock are the same. Just install them with the shraeder nitrogen valve at the top of vehicle.



## Step 7 — Installing Right & Left Rear Shock



- On Stage 2, Stage 4, and Stage 5 models the rebound adjuster located on lower eyelet of the shocks should be oriented towards the rear of the vehicle, as shown. (Shown by the red square ). If needed, you can turn the lower eyelet to orient properly.