



Yamaha RAPTOR 125 (ALL YEARS)

Written By: Steve Boulay



INTRODUCTION

READ BEFORE INSTALLATION

- Never unscrew the banjo bolts of the hose to reorient them
- Do not bend the hoses at a 90° angle
- Do not route the hoses near a place where it can rub or be pinched
- Do not route the hoses near extreme heat-generating parts (ie: exhaust)
- Do not over tighten the metal collars on the reservoir (torque to 6 lb/in)
- Make sure the reservoir and hose stay clear of any moving parts
(ie: swingarm, chain)
- Hoses can be secured to the frame using zip ties to avoid contact with moving parts
- Make sure that the shock bolts and metal collars are tightened properly before riding

Step 1 — REAR SETUP



- Lift the vehicle off the ground with a jack or on a stand. Remove the stock shock absorbers from the vehicle (refer to the manufacturer's documentation).
- Install the Elka shock absorbers bolting the top mount first. The banjo (connected to the shock head) must face towards the front of the vehicle. Orient the hose towards the left side of the vehicle.


Step 2 — REAR SETUP



- The rebound adjuster (adjustable using a screwdriver) located at the bottom of the shock should face the




top of the quad for convenient access.

Step 3 — REAR SETUP



- Install the reservoir with the banjo bolt (connected to the reservoir) facing towards the top of the vehicle. Orient the hose towards the front of the vehicle. The reservoir must be attached to the frame using the provided rubber holders and metal collars. **Do not overtighten the metal collars on the reservoir (torque to 6 lb.in).**
- Make sure to route the hose according to the pictures. Remove the plastic cover on the left side of the vehicle to pass the reservoir. The compression adjustment knobs should be facing the bottom of the vehicle for convenient access. Re-install the plastic cover.
- ① Refer to the Elka owner's manual to set the ride height and for adjustment procedures.
- Installation is complete.

Step 4 — FRONT SETUP



- Lift the vehicle off the ground with a jack or on a stand. Remove the stock shock absorbers from the vehicle (refer to the manufacturer's documentation).
- Install the Elka shock absorbers with the piggyback reservoirs towards the top and the adjustment knobs towards the outside of the quad. Make sure the rebound adjuster screw (if such equipped) is facing towards the inside of the quad. Tighten the top mounting bolt then the lower mounting bolt.
- Refer to your Elka Owner's Manual for instructions on how to set the ride height and for adjustment procedures.
- Installation is complete.